

Funzione Traccia su Power Commander 3usb

La funzione "Traccia" evidenzia la cella della mappatura interessata durante il funzionamento del motore. Per attivare la funzione:

- 1) Avviare il software Power Commander 3 USB
- 2) Accendere il quadro della moto.
- 3) Premere contemporaneamente i tasti "CTRL + T", comparirà la casella gialla come mostrato di seguito:

The screenshot shows the Power Commander 3 USB interface. On the left, there are buttons for map operations: Apri Mappa, Salva Mappa, Invia Mappa, Invia Tavola, Ricevi Mappa, Ricevi Tavola, and Mostra Note. The main area is a table titled "Tavola Benzina 1" and "Tavola Accensione 1" showing the relationship between RPM (500 to 7000) and % Apertura Acceleratore (0, 2, 5, 10, 20, 40, 60, 80, 100). The cell for 5000 RPM and 5% throttle is highlighted in yellow. On the right, there are digital displays for % Farfalla (0), Giri/Min (0), Diff. Benzina (0), Duty Cycle (00), and Accensione (0).

- 4) Avviando il motore la traccia gialla evidenzierà sulla mappatura il punto di incrocio dei valori %Farfalla e Giri/Min mostrati sul lato della finestra software.

This screenshot shows the same software interface as the previous one, but now the engine is running. The digital displays on the right show % Farfalla at 5 and Giri/Min at 4998. Red arrows point from these values to the corresponding cell in the fuel map table (5000 RPM, 5% throttle), which is now highlighted in yellow. The other digital displays (Diff. Benzina, Duty Cycle, Accensione) also show updated values.