


- 1) Dal sito www.dynojet.com cliccare sul link TUNES :
<https://www.dynojet.com/tunes>
- 2) Attendere il caricamento della pagina e selezionare il tipo di centralina (PRODUCT)
- 3) Procedere selezionando la tipologia di veicolo (TYPE), l'anno (YEAR), la marca (MAKE) ed il modello (MODEL)



- 4) Selezionare la mappa indicata per la configurazione della propria moto, qui per la traduzione dei termini più comuni :
<https://www.powercommander.it/it/pdf/manuali/Pc-Termini-Ingl-Mappe.pdf>

- 5) Cliccare su Login per accedere al download

The screenshot shows the Dynojet website's 'TUNES' section. The browser address bar displays 'https://www.dynojet.com/tunes'. The page features a navigation menu with categories like 'POWER COMMAND...', 'MOTORCYCLE', '2007', 'SUZUKI', and 'C90-R1000'. A search bar contains the text 'Search tunes by keyword'. Below the search bar, there are filters and a 'DOWNLOAD POWER VISION 2 OR CX TUNES' button. The main content is a table with 10 rows of exhaust parts, each with a 'MAP', 'DESCRIPTION', and 'DOWNLOAD' link. The table is followed by pagination information: 'Records: 1 - 10 of 55 - Pages: < 1 2 3 4 5 6 >'. At the bottom, there is a newsletter sign-up form with the text 'Sign Up For Our Newsletter:' and an input field for 'Enter your email:'.

MAP	DESCRIPTION	DOWNLOAD
20-024-001	Stock exhaust Stock air filter	Login
20-024-002	Two Brothers slip on exhaust.Stock or aftermarket air filter	Login
20-024-003	Leo Vince full exhaust Stock or aftermarket air filter	Login
20-024-004	TI Force high mount full exhaust Stock or aftermarket air filter	Login
20-024-005	Two Brothers dual flange on mufflers Stock or aftermarket air filter	Login
20-024-006	M4 full exhaust system GP silencer Insert removed Stock or aftermarket air filter	Login
20-024-007	M4 full exhaust system (standard mount) Stock or aftermarket air filter	Login
20-024-008	Leo Vince single slip on (eliminates catalytic converter) Stock or aftermarket air filter	Login
20-024-009	Arata full exhaust system Stock or aftermarket air filter	Login
20-024-010	M4 slip on exhaust (insert removed) Stock or aftermarket air filter	Login

6) Inserire le proprie credenziali (User Name e Password)
Se necessario creare un account.

LOGIN

NOTE: TO PURCHASE LICENSES PLEASE CLICK HERE

EMAIL *

PASSWORD *

Keep me logged in

[Forgot Password?](#)

LOG IN

Don't have an account? [Create an Account](#)

OR

 GOOGLE

 FACEBOOK



NOTA: Le mappe in formato Pc5 possono essere utilizzate anche su Power Commander 3usb, Power Commander FC e Power Commander 3 (con porta seriale)
Qui tutte le versioni software Power Commander da scaricare:
<https://www.powercommander.it/it/software.php>

Power Commander 3usb e 3 (seriale) :

- Scaricare ed installare il software per PowerCommander 5, e aprire la mappa.

- Copiare i valori dalla mappa Pc5 selezionando più colonne intere (0% / 10% farfalla, poi tasto destro-> Copy)
- Aprire il software Pc3usb (o Pc3 seriale) e incollarle i valori delle colonne 0% / 10% farfalla con tasto destro -> Incolla.
- Ripetere l'operazione per le colonne 20% / 100% farfalla.
- Premere il pulsante Invia Mappa (Invia Tutto nel caso del Pc3 seriale)

Video tutorial:

<https://www.dropbox.com/s/skgk49ybn8d85zr/CopiaMappe.webm?dl=0>

Power Commander FC:

- Cliccare il menu File -> Import Power Commander Map e scegliere la mappa da caricare
- Premere il pulsante Send Map
- Selezionare la posizione in cui inserire la mappa.